

INSTALLATION INSTRUCTIONS

PRODUCT: ALL LIGHTS ON™

INSTRUCTIONS FOR: 2006-2011 Cadillac DTS

ESTIMATED INSTALLATION TIME: 15 minutes

FPE-2023-10
December, 2023
Page 1 of 1

STEP 1: Remove the trim panel below the glovebox by pulling it downwards. Remove the glovebox. To remove, locate the three 7mm bolts on the underside of the glovebox. Open the glovebox and remove the four 7mm bolts on the top side. As you remove the glovebox, disconnect the two electrical connectors for the lights.

STEP 2: Locate the Body Control Module (BCM) beside the glovebox on the passenger side of the vehicle. The BCM will have 7 connectors, each a different color. You will be removing the black connector.

STEP 3: Disconnect the black connector from the bottom of the BCM. Remove any tape or wrap to expose enough of the wires to install the All Lights On™ module (3-4 inches).

STEP 4: Locate pin 11 (fog lamp signal). The wire is *dark green with a white stripe*. From the bottom right side of the connector, count over 8 pins and up 2 pins to locate the wire. Route this wire through the circuit board and connection labeled "fogs".


STEP 5: Locate Pin 16 (high beam signal). The wire is *brown or tan with a white stripe*. From the bottom right side of the connector, count over 3 pins and up 2 pins to locate the wire. Route this wire through the circuit board and connection labeled "highs".

STEP 6: Position the cover over the wires and squeeze it downward with a pair of pliers to force the wires into the insulation displacement prongs. Install the black connector back into the BCM.


NOTE: The connector cover is a one-time use part. Double check the pin locations before installing the cover, it cannot be removed and re-used.

STEP 7: Reinstall the glove box, then install the panel below the glovebox by pressing it back into place.

Operation: Low beams and fog lights will operate normally. When high beams are activated, the fog lamps will remain on with the high beams.




Pin 11, Fog Light Signal



Pin 16, High Beam Signal



Route wires as shown



Install cover to seat wires